



Installation and Setup Instructions AFF8020 Systems





Prepare for installation










Rack space Screwdriver 6U per chassis





For connecting your storage to your network switch and Microsoft® Windows® client



Microsoft Windows® client
Runs the software to configure
your storage system





- FC SAN Optimized AFF Setup Guide https://library.netapp.com/ecm/ecm_download_file/ECMP12462582
- Using All Flash FAS with Clustered Data ONTAP https://library.netapp.com/ecm/ecm_download_file/ECMP12466574
- NFS optimized NFS volumes in the System Manager Online Help










Unpack and install system

- Unpack all boxes and inventory contents.
- Install rail kits, as needed, using the enclosed installation instructions.
- Install system components on rails or in a system cabinet per installation instructions.
- Attach cable management arms.
- Place the bezel on the front of the system.



FRONT VIEW OF SYSTEM





Cable controller to switches

See your network administrator for help connecting to your switches.



Cluster interconnect cable PN 112-00297 or 112-00299

Cable the cluster interconnect e0a to e0a and e0b to e0b ports on both controllers.

Ethernet cables

Connect wrench ports to the management switches (for cluster and node mgmt. LIFs).


Connect e0e ports to the management switches (for SVM mgmt. LIFs).

10GbE Network cables PN 112-00299 or 112-00300 or 112-00301

Connect e0c|0c and e0d|0d ports to data switches.


4 Strap the cables to the cable management arms. (Not shown)

Two node switchless cluster, clustered Data ONTAP






DO NOT install power cables at this point.








One stack with one disk shelf










Complete System Setup and configuration (Choose option A or B below)



- Factory configured FC SAN or NFS Optimized Systems
- **Cable Windows client to same** network as your controllers



Set client networking configuration:

TCP/IP address: 10.10.10.20 Netmask: 255.255.255.0 **Gateway: 10.10.10.1**

Power on all disk shelves

Refer to documentation shipped with disk shelves for details

Connect power cables to controllers Both power supplies MUST be powered on.

Power on controllers May take up to 10 mins

- **Log into System Manager**
 - Enter IP: 10.10.10.10 Note: Ignore the security warnings about an untrusted site
 - User name: admin Password: netapp!123
- Provision storage for your AFF system
 - Complete the AFF SAN and/or NFS Optimized Installation Worksheet for your system type from your shipment box or from: https://library.netapp.com/ecm/ecm_download_file/ ECMLP2432838.
 - Complete the storage provisioning wizards for your system. The wizards either automatically start when you log into the system or you can access them in the Storage Applications tab under Storage Virtual Machines.
- For advanced setup and preparation, go to:

SAN: https://library.netapp.com/ecm/

ecm_download_file/ECMP12462582

NFS: See NFS optimized NFS volumes in the


System Manager Online Help.

All other AFF Systems

Complete configuration worksheet

From http://mysupport.netapp.com/NOW/public/ system_setup/

Cable Windows client to same network as your controllers



- Connect disk shelf power cables and power on all disk shelves only
- Install and run System Setup software

*If you cannot use System Setup, see the Data ONTAP Software Setup Guide.

- Install System Setup software
- Connect the power cables to the controllers. Do not power on your system until directed by System Setup software Both power supplies MUST be powered on.
- the system.

Wait for discover to complete



- Enter the values from the configuration worksheet into System Setup.*
- Register at mysupport.netapp.com
- **Download and run Config Advisor** http://mysupport.netapp.com/NOW/download/tools/ config_advisor/
- **Run OnCommand System Manager**
 - Enter node's IP address.
 - Provision storage.
 - Configure other protocols, data protection, and AutoSupport.
 - Set up Service Processor and Remote Support Agent.
 - Using All Flash FAS with Clustered Data ONTAP https://library.netapp.com/ecm/ecm_download_file/ ECMP12466574





Visit the NetApp web site for more information.

- Using all Flash FAS with Clustered Data ONTAP: https://library.netapp.com/ecm/ecm_download_file/ECMP12466574
- Data ONTAP 8 library:
- http://mysupport.netapp.com/documentation/productlibrary/index.html?productID=30092
- Controller and configuration examples; Universal SAS and ACP Cabling Guide: https://library.netapp.com/ecm/ecm_download_file/ECMM1280392
- OnCommand System Manager documentation set:
- http://mysupport.netapp.com/documentation/productlibrary/index.html?productID=61372
- Hardware Universe: https://hwu.netapp.com/
- NFS optimized NFS volumes: System Manager Online Help



