

## Replacing a fan module in a 62xx system

To replace a fan module, you must perform a specific sequence of tasks.

### About this task

The fan module is hot-swappable and can be replaced without interrupting service.

1. [Removing a fan module](#) on page 1
2. [Installing a fan module](#) on page 2
3. [Completing the replacement process](#) on page 3

## Removing a fan module

You can remove a fan module without powering down the system.

### About this task

**Attention:** You must replace the fan module within two minutes of removing it from the chassis. System airflow is disrupted and the controller module or modules shut down after two minutes to avoid overheating.

If the system is in a single-enclosure HA pair or dual-enclosure HA pair configuration, only the controller module associated with that fan shuts down after the two-minute window. The partner controller module continues to serve data without interruption.

### Steps


1. If you are not already grounded, properly ground yourself.
2. Remove the bezel (if necessary) with two hands, by grasping the openings on each side of the bezel, and then pulling it toward you until the bezel releases from the four ball studs on the chassis frame.
3. Identify the fan module that you must replace by checking the console error messages and looking at the Status LED on each fan module cam handle.

A failed fan module LED is solid amber, indicating that the fan module failed. No LEDs are lit if the fan module is not receiving power.

4. Press down the release latch on the fan module cam handle and pull the cam handle downward.

The fan module moves a little bit away from the chassis.





1	Cam handle
2	Fan module
3	Cam handle release latch
4	Fan module status LED

5. Pull the fan module straight out from the chassis, making sure that you support it with your free hand, so that it does not swing out of the chassis.

**Attention:** The fan modules are short. Always support the bottom of the module with your free hand so that it does not suddenly drop free from the chassis and injure you.

6. Set the fan module aside.

## Installing a fan module

To install a fan module, you must perform a specific sequence of steps.

### Steps

1. If you are not already grounded, properly ground yourself.
2. Remove the bezel, if necessary.

3. Insert the replacement fan module into the chassis by aligning it with the opening and sliding it into the chassis.
4. Push firmly on the fan module cam handle to ensure that it is seated all the way into the chassis.

The cam handle raises slightly when the fan module is completely seated.

5. Swing the cam handle up to its closed position, making sure that the cam handle release latch clicks into the locked position.
6. Reinstall the bezel.
7. Run diagnostics on the replacement fan module during the next scheduled system downtime.

See the *System-Level Diagnostics Guide* on the NOW site for more information.

#### Related information

*System-Level Diagnostics Guide: [now.netapp.com/NOW/knowledge/docs/hardware/NetApp/diag/sldiag.pdf](http://now.netapp.com/NOW/knowledge/docs/hardware/NetApp/diag/sldiag.pdf)*

## Completing the replacement process

After you replace the part, you can return the failed part to NetApp, as described in the RMA instructions shipped with the kit. Contact NetApp technical support at 888-463-8277 (North America), 00-800-44-NETAPP (Europe), or +800-800-80-800 (Asia/Pacific) if you need the RMA number or additional help with the replacement procedure.

---

## Trademark information

NetApp; the NetApp logo; the Network Appliance logo; Bycast; Cryptainer; Cryptoshred; DataFabric; Data ONTAP; Decru; Decru DataFort; FAServer; FilerView; FlexCache; FlexClone; FlexShare; FlexVol; FPolicy; gFiler; Go further, faster; Manage ONTAP; MultiStore; NearStore; NetCache; NOW (NetApp on the Web); ONTAPI; RAID-DP; SANscreen; SecureShare; Simulate ONTAP; SnapCopy; SnapDrive; SnapLock; SnapManager; SnapMirror; SnapMover; SnapRestore; SnapValidator; SnapVault; Spinnaker Networks; Spinnaker Networks logo; SpinAccess; SpinCluster; SpinFlex; SpinFS; SpinHA; SpinMove; SpinServer; SpinStor; StorageGRID; StoreVault; SyncMirror; Topio; vFiler; VFM; and WAFL are registered trademarks of NetApp, Inc. in the U.S.A. and/or other countries. Network Appliance, Snapshot, and The evolution of storage are trademarks of NetApp, Inc. in the U.S.A. and/or other countries and registered trademarks in some other countries. The StoreVault logo, ApplianceWatch, ApplianceWatch PRO, ASUP, AutoSupport, ComplianceClock, DataFort, Data Motion, FlexScale, FlexSuite, Lifetime Key Management, LockVault, NOW, MetroCluster, OpenKey, ReplicatorX, SecureAdmin, Shadow Tape, SnapDirector, SnapFilter, SnapMigrator, SnapSuite, Tech OnTap, Virtual File Manager, VPolicy, and Web Filer are trademarks of NetApp, Inc. in the U.S.A. and other countries. Get Successful and Select are service marks of NetApp, Inc. in the U.S.A.

IBM, the IBM logo, and ibm.com are trademarks or registered trademarks of International Business Machines Corporation in the United States, other countries, or both. A complete and current list of other IBM trademarks is available on the Web at [www.ibm.com/legal/copytrade.shtml](http://www.ibm.com/legal/copytrade.shtml).

Apple is a registered trademark and QuickTime is a trademark of Apple, Inc. in the U.S.A. and/or other countries. Microsoft is a registered trademark and Windows Media is a trademark of Microsoft Corporation in the U.S.A. and/or other countries. RealAudio, RealNetworks, RealPlayer, RealSystem, RealText, and RealVideo are registered trademarks and RealMedia, RealProxy, and SureStream are trademarks of RealNetworks, Inc. in the U.S.A. and/or other countries.

All other brands or products are trademarks or registered trademarks of their respective holders and should be treated as such.

NetApp, Inc. is a licensee of the CompactFlash and CF Logo trademarks.

NetApp, Inc. NetCache is certified RealSystem compatible.

